


PLEASE READ ALL INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION.

- 1. Flip both rear seat bottoms up so they are secured in the upright position.
- 2. Remove the OEM outermost seat mount bolt that secures the 60% portion of the rear seat to the floor.
- 3. Place a #13.2 Carriage Bolt through one of the #11 Mounting Brackets as shown in Figure 1.
- 4. Slip the bracket under the seat mount so that the mounting hole is visible from above.
- 5. Replace, but do not tighten, the OEM bolt removed in step #2.
- 6. Repeat steps #2 thru #5 on the mounting bolt that secures the other side of the 60% rear seat.
- 7. Place the #344 Lockbox in the floorboard area of the vehicle and slide it back into place so that the #13.2 Carriage Bolts protrude through to the inside of the box. The Carriage Bolts may need to be moved in the horizontal slots of the #11 Brackets to line up properly with the vertical slots in the rear of the Lockbox.
- 8. Install the #13.3 Washers, and #13.1 Wing Knob Nuts. (See Figure #2) NOTE: Do not tighten #13.1 Nuts as some adjustability is required in the next steps.
- 9. Adjust the Lockbox's side to side position so that the lid doesn't touch the smaller seat as it is lifted and lowered.
- 10. Once the Lockbox is in its final position, the (2) #13.1 Wing Knob Nuts and the OEM Seat Mount Bolts may be tightened.



Call (800) 348-8339 for Technical Support.

Page 2 of 2 - 5/7/2018 - Rev051414