


TJ-YJ-CJ RICOCHET ROCKERS & ROCKER KNOCKERS INSTALLATION



Thank you for purchasing Poison Spyder Ricochet Rockers (shown above) or Rocker Knockers for your Jeep CJ, YJ or TJ. You now own the ultimate in rocker panel protection for your Jeep. If you purchased Rocker Knockers with the Slider option, these have already been welded to the Rocker Knockers and install in the same manner, as do the Ricochet Rockers. Installation is fairly simple with the right tools and good mechanical abilities. If you are not confident in your mechanical skills, please seek the help of a professional to perform the installation. Please read through these entire instructions before proceeding with installation.

PARTS LIST

- (1) Driver side Rocker Klocker
- (1) Passenger side Rocker Klocker
- (x) 3/8-16 X 1 SS flat head cap screw*
- (x) 3/8 flat washer*
- (x) 3/8-16 nylon insert lock nut*

*Quantity "x" varies by Jeep model:

- (10) TJ
- (12) CJ-5 & YJ
- (14) CJ-7

TOOLS NEEDED

- 9/16" socket or end wrench
- 5/8" socket

- 6" socket extension
- Ratchet
- 7/32" hex key or hex socket
- Auto-punch or center punch and hammer
- Drill motor
- 3/8" drill bit
- Torque wrench
- Touch-up paint or clear coat
- Floor jack and extension

BEFORE YOU BEGIN

- Paint or powdercoat both the inside and outside of the Rocker Knockers. If painting them yourself, take the time to do a thorough job cleaning the Rockers and making sure they are completely free of dirt, grease or oils, solvents or cleaner residue. Sanding or scuffing the surface will also help the primer and paint to adhere. Use a quality etching primer, then paint in your color of choice.
- Park the Jeep on a flat, level surface and set the emergency brake.
- Be sure that the sides and undercarriage of the vehicle, in the areas you will be working, are clean and clear of debris and mud.
- Remove any plastic flares that are bolted to the side of the body (some TJ's and YJ's).

Remove any existing rocker panel molding (some CJ's), or any existing OEM rocker panel covers (all Rubicons and Saharas).

- While not required, it is helpful to loosen the lower three bolts that hold the OEM flares in place at the lower end.

INSTALLATION PROCEDURE

1. **Loosen all of the** body mounts on the driver side of the Jeep.
2. **Raise the driver side** of the body with a floor jack and extension. Be sure to position the jack pad at or near a body support to avoid damage to the body tub.
3. **Remove the body mount** bushings that are in Rocker Knocker mounting slot locations.
4. **Measuring from the top**, cut 3/16" off the top of the body bushing to allow for Rocker Knocker clearance.
5. **Re-install the body bushings** (and body lift spacers, if used), and all hardware.
6. **Slide Rocker Knocker into** position, with the body mount bolts passing through the slots in the Rocker Knocker. The Rocker Knocker should be above the body mount bushing, as shown in figure 1. .



FIGURE 1

Make sure the Rocker Knocker is pressed firmly against the side of the Jeep, then gently lower the driver side body back down onto the body mounts.

7. **Check all mounting positions** for proper placement. Step back and observe the front-to-back position of the Rocker Knocker, and make any necessary adjustments. With the Rocker Knocker correctly positioned, clamp it firmly to the Jeep's body with C-clamps, vise-

grip clamps or similar (at least one clamp at each end).

8. **Use a fine-tip felt** marker to mark all of the 3/8" mounting holes along the top side of the Rocker Knocker.
9. **Remove the clamps**, use the jack to carefully lift the driver side of the body once again, remove the Rocker Knocker and set it aside.
10. **Use an auto-punch or** center-punch and hammer to center-punch the drill marks for each of the hole locations marked in step 9.
11. **Check behind the Jeep's** rocker panels for wiring, fuel lines or any other obstructions where the holes are to be drilled. Temporarily hold away or remove any such obstructions.
12. **Drill each of the** marked hole locations with a sharp 3/8" drill bit. De-burr the edges of the holes with a file, sander or burr knife.
13. **On CJ's and 2003+** TJ/LJ, an access hole will need to be drilled from the inside of the tub to access the area where the rear-most nut will be installed. Use a 1" hole saw. After installation is complete, this hole can be plugged with a rubber CJ body plug.
14. **Use touch-up paint or** clear coat to coat the bare metal edges of the drilled holes.
15. **Re-position the Rocker Knocker** into place. Reinstall the body mount pieces in the order from which they were removed. Lightly tighten the body mount bolts.
16. **Install a stainless steel** flat head cap screw at each of the countersunk holes in the Rocker Knocker. Secure with a flat washer and nylon insert lock nut on the back side of the Jeep body tub. Tighten all hardware to specs. Re-install flares (if applicable)
17. **Repeat process for** passenger side.

WARRANTY

Poison Spyder Customs™ warranties all of the products we sell and distribute for one (1) year from the date of sale. These products will be free from defects in material and workmanship under normal installation, and use. Due to the intended use the powder coat finish is warranted for ninety (90) days. The finish warranty will not cover a product if it has been damaged in any

way. Warranty is limited to repair or replacement. Poison Spyder Customs™ does not offer any type of labor or shipping allowance and all warranty claims are subject to inspection by Poison Spyder Customs™.

At the discretion of Poison Spyder Customs™, the products in question can be repaired or replaced when found defective. Prior to any replacement or repair, written authorization must be obtained from Poison Spyder Customs™. Failure to contact us prior to having warranty work preformed will immediately void all applicable warranties; and it is then the sole responsibility of the customer to remit any payment incurred.

The warranty expressed above is the sole warranty of Poison Spyder Customs™, and any other expressed or implied warranties are hereby specifically excluded and disclaimed.

HOLD HARMLESS AGREEMENT

1. In purchasing a Poison Spyder Customs Product™ I release, waive, discharge and covenant not to sue Poison Spyder Customs officers, servants, agents, or employees (hereinafter referred to as Releasees) from any and all liability, claims, demands, actions and causes of action whatsoever arising out of or related to any loss, damage, or injury, including death, that may be sustained by me (or anyone else), any property belonging to me (or anyone else), whether caused by the negligence of the releasees or otherwise, while working on, using or any activity related to this product.
2. I am fully aware of risks and hazards connected with the use of a this product and I elect to voluntarily engage in such use of this product knowing that the use may be hazardous to me and my property. I voluntarily assume full responsibility for any risks of loss, property damage or personal injury, including death, that may be sustained by me (or anyone else), or any loss or damage to property owned by me (or anyone else), as a result of using this product, whether caused by the negligence of releasees or otherwise.
3. I further agree to indemnify and hold harmless the releasees from any loss, liability, damage or costs, including court cost and attorney fees, that they may incur due to my use of a

this product, whether caused by negligence of releasees or otherwise.

4. It is my express intent that this Release and Hold Harmless Agreement shall bind the members of my family and spouse, if I am alive, and my heirs assigns and personal representative, if I am deceased, and shall be deemed as a release, waiver, discharge, and covenant not to sue the above named releasees. I further agree that this Waiver of Liability and Hold Harmless Agreement shall be construed in accordance with the laws of the State of California.

By accepting this product, I acknowledge and represent that I have read the above Waiver and Liability and Hold Harmless Agreement, understand it and accept it voluntarily as my own free act and deed; no oral presentations, statements, or inducements, apart from the foregoing written agreement, have been made; I am at least eighteen (18) years of age and fully competent; and I execute this Release for full, adequate and complete consideration fully intending to be bound by same.

If you do not agree with the preceding Hold Harmless Agreement, you may return the product and receive a full refund. Please, contact a Poison Spyder Customs™ sales representative and they will issue a call tag for the product in question. Once the product has been received by Poison Spyder Customs™ a full refund will be issued.

INSTALLATION INSTRUCTIONS