



**RUST  
BUSTER**  
FRAMEWORKS

RB1011L & RB1011R

Jeep CJ  
Skid Plate Frame Section



**VIDEO AVAILABLE**

=



**REQUIRED TOOLS**

Jack Stands or Lift  
Mig Welder  
Paint/Primer  
Locking Pliers  
Hand Grinder  
Cutting Wheel or Torch  
Welding Gloves  
Welding Hood/Shield  
Ear & Eye Protection  
Sockets & Ratchet  
Fire Extinguisher & Water

**KIT CONTAINS**

Skid Plate Frame Section  
3/8" Hex Bolt

**QTY**

1  
3

1011L & RB1011R00



**RUST  
BUSTER**  
F R A M E W O R K S

RB1011L & RB1011R

**Jeep CJ  
Skid Plate Frame Section**

**1) PREPARING YOUR VEHICLE**

Begin by disconnecting your battery prior to starting your installation.

Inspect your vehicle for leaking fuel lines, fuel tank and engine components. If you have fuel leaks repair all leaks prior to starting your installation. If your fuel tank is near your welding area **remove your tank prior to welding.**

Remove all combustible items above the work area such as seats, carpets, padding, etc.

**Keep all flammable materials away from the vehicle work area.**

**2) PREPARING YOUR WORKSTATION**

Keep a fire extinguisher and water close by in the case of fire and make sure you always have a designated "Fire Watch" to assist during the cutting or welding phases.

Abide by all apprenticed welding safety standards and practices.

Always use appropriate welding eye protection, ear protection, and work and fire safety gloves during the installation and within the work area.



**WARNING!**

If you are unsure on how to perform the installation or how to operate any of the required tools listed above, it is **HIGHLY** advised that you enlist the work of a certified welder/installer.

Failure to follow proper safety precautions and instructions may result in serious injury. **The user assumes all liability when installing the product.**



# RUST BUSTER

FRAMEWORKS

RB1011L & RB1011R


## Jeep CJ Skid Plate Frame Section

### 3) PREPARING FOR YOUR INSTALL

Lift or Jack your vehicle, and support it with jack stands. Support your drivetrain with a jack stand as the skid plate is structural and holds it in place.



With a 1/2in socket, remove the 8 bolts and nuts retaining your skid plate.



Hold the part up to the frame while using the frame holes and brackets for alignment and positioning.

Take note of its coverage and mark your limits if needed.



### 4) CUT AND CLEAN

Clean and cut the frame of any rust and debris, revealing bare metal, while leaving enough frame behind to weld back on to.



Replace the part while using the frame holes and brackets for alignments and positioning, and C-clamp it to the frame.



# RUST BUSTER

F R A M E W O R K S

RB1011L & RB1011R

Jeep CJ

Skid Plate Frame Section

5) **WELD**

Begin welding around all edges, and along the weld slots.



6) **COAT AND REINSTALL**

Coat the part and work area with a primer to help protect against rust development.



**COAT THE WORK AREA WITH A PRIMER TO HELP PREVENT RUST**

Begin reinstalling your skid plate with the included hardware.

